



LIST OF SPARES / ERSATZTEILLISTE / LISTE DE PIÈCES DE RECHANGE / LISTA RICAMBI

Item No. Art.-Nr. Référence N° di parte	Description Bezeichnung Description Descrizione	Pack Pckg. Pack Confezione	HR2028
1	Assembly/Buffer Pack Baugruppen/Puffer-Satz Ensemble/Pack de tampons Confezione complessivo/Respingente	pack	HR2028/1
2	Coupling pack Kupplungssatz Pack d'attelage Confezione attacco	pack	HR2028/2
3	Drive Unit Antrieb-Satz Unité d'entraînement Trasmissione	1	HR2028/3
4	Bogie Assembly D reghestell Bogie Carrello	1	HR2028/4
5	Chassis Chassis Châssis Telaio	1	HR2028/5
6	Lights board Lichtleiterplatte Carte de circuit imprimé Éclairage Scheda circuito stampato luci	1	HR2028/6
7	Main PCB board Hauptleiterplatte Carte principale de circuit imprimé Scheda principale a circuiti Stampati	1	HR2028/7
8	Motor Pack Motor-Satz Pack moteur Confezione motore	1	HR2028/8
9	Universal shaft pack Universal-Wellensatz pack Axle Universel Confezione Albero Universale	10	HR2028/9
10	Assembly Pack (For Tender) Baugruppen-Satz (für Tender) Pack de Montage (pour tender) Confezione Complessivo (per tender)	1	HR2028/10
11	Traction Tyres Pack Haftreifen Pneus de Traction Pneumatici Trazione	pack	HR2028/11
12	Valve Gear / Coupling Rods Steuer-/Treibgestänge/Kupplungsstangen Jeu de distribution/Bielles d'accouplement Trasmissione/Bielle di collegamento	set	HR2028/12
13	Wheel set (drive unit) Radsatz für Antrieb Jeu de roues unité motrice Azionamento set ruote	2	HR2028/13

