

### LISTA RICAMBI / ERSATZTEILLISTE / LIST OF SPARES

N° di parte Teil-Nr. Item No.	Descrizione Bezeichnung Description	
		HR2316
1	Carrozzeria Gehäuse Bodyshell	HR2316/01
2	Confezione attacco Kupplungssatz Coupling Pack	HR2316/02
3	Supporto motore e cover Motorhalterung und-abdeckung Motor support and cover	HR2314/03
4	PCB Leiterplatte PCB board	HR2314/04
5	Confezione motore Motor Motor pack	HR2314/05
6	Gradini Führerstandsleitern Steps	HR2315/06
7	Telaio Chassis Chassis	HR2316/07
8	Azionamento set ruote Radsätze Wheelsets	HR2314/08
9	Ingranaggi ed assi Zahnräder und Achsen Gears and axles	HR2314/09
10	Cover scatola ingranaggi Bodenabdeckung Bottom cover	HR2314/10
11	Accessori (mancorrenti, tergicristalli, etc) Kleinteile (Scheibenwischer, etc.) Small pieces (wipers, hooks, buffers, etc.)	HR2316/11

