



LIST OF SPARES / LISTA RICAMBI / ERSATZTEILLISTE

Part No. N° di parte Teil-Nr.	Description Descrizione Bezeichnung	Spare part ref. N° di ricambi Ersatzteil-Nr.
5	Coupler pack Confezione attacco Kupplungssatz	HR2637/05
12	Front bogie tender (with wheels) Carrello anteriore tender (con ruote) Drehgestell vorn (Tender, mit Rädern)	HR2357/12
14	Wheel set (Tender) Set ruote (Tender) Radsatz (Tender)	HR2357/14
21	Rear tender pony truck Carrello posteriore tender (con ruote) Drehgestell hinten (Tender, mit Rädern)	HR2357/21
22	Bogie springs Molle carrello Drehgestellfedern	HR2357/22
24	Pack of tender front and end side for UP 4014 with fuel tender Parti anteriori e posteriori per UP 4014 con tender a nafta Tenderfront- und endseiten für UP 4014 mit Öltender	HR2884/24
27	Screw pack (for tender) Confezione viti (per tender) Schrauben-Satz (für tender)	HR2357/27